

CORRIGENDUM

La correction ne concerne que le texte anglais

Page 29

(1) *Method for assigning the diameter code*

Instead of

The diameter code number is the integer of the maximum height of the battery expressed in mm

Read

The diameter code number is the integer of the maximum diameter of the battery expressed in mm

Page 36

Remplacer les deux lignes du tableau IX comme suit

Page 37

Replace both lines of table IX as follows

2R3845	2R5	34,0	17,0	45,0
2P4036	R-P2	35,0	19,5	36,0

Page 50

NOTE – MÉTHODE D'UTILISATION DU SYMBOLE ISO 7000-1135 SUR LES PILES

Au lieu de

- c) Toutes les dimensions "ISO" sont exprimées en fonction de la dimension "a", l'écartement des repères d'angle mentionné ci-dessus correspond à 2/3 de la dimension "a"

Lire

- c) Toutes les dimensions "ISO" sont exprimées en fonction de la dimension "a", l'écartement des repères d'angle mentionné ci-dessus correspond à 3/2 de la dimension "a"

Page 51

NOTE – METHOD OF PRESENTATION OF THE SYMBOL ISO 7000-1135 ON PRIMARY BATTERIES

Instead of

- c) All "ISO" dimensions are expressed in relation to the "a" dimension, the pitch of the right angles mentioned above being 2/3 of the dimension "a"

Read

- c) All "ISO" dimensions are expressed in relation to the "a" dimension, the pitch of the right angles mentioned above being 3/2 of the dimension "a"